



1. Locate SORAPRO within 10' of the Service Panel
2. Install a 2p20A dedicated breaker in the Service Panel
The breaker must be installed in the same panel that the CT's will be measuring from.
3. Install a neutral reference wire as well as a ground wire per NEC code requirements.
4. Attach the PV CT's as shown, making sure they are facing the proper direction of current flow. Do not use I_{31} or I_{32}
5. Connect an Ethernet line from the Data Acquisition device to the Internet Router as shown.

