



1. Locate SORAPRO within 10' of the Service Panel
2. Install a 3p20A dedicated breaker in the Service Panel. The breaker must be installed in the same panel that the CT's will be measuring from.
3. Install a Neutral reference as well as a Ground wire per NEC code requirements.
4. Attach the CT's as shown in the CT terminal block, making sure they are facing the proper direction of current flow.
5. Connect an ethernet line from the Data Server to the Internet Router as shown.

